

TABULKY PŘÍSLUŠENSTVÍ

MOŽNOSTI MONTÁŽE ŠROUBOVACÍCH ELEKTRICKÝCH TOPNÝCH JEDNOTEK ŘADY TJ

Typ	TJ 6/4" - 2 *	TJ 6/4" - 2,5 *	TJ 6/4" - 3,3	TJ 6/4" - 3,75 *	TJ 6/4" E - 3,75 *	TJ 6/4" - 4,5 *	TJ 6/4" E - 4,5 *	TJ 6/4" - 6 *	TJ 6/4" E - 6 *	TJ 6/4" - 9 *
OKCE 200 S	▲	▲	▲	▲		▲		▲		-
OKCE 250 S	▲	▲	▲	▲		▲		▲		-
OKCE 300 S	▲	▲	▲	▲		▲		▲		-
OKCE 500 S	▲	▲	▲	▲		▲		▲		-
OKC 200 NTR/BP	▲	▲	▲	▲		▲		▲		-
OKC 300 R/BP/S	▲	▲	▲	▲		▲		▲		-
OKC 500 R/BP/S	▲	▲	▲	▲		▲		▲		-
OKC 750 NTR/BP	▲	▲	▲	▲		▲		▲		▲
OKC 1000 NTR/BP	▲	▲	▲	▲		▲		▲		▲
OKF 200 NTR/S	▲	▲	▲	▲		▲		▲		-
OKC 300 R/F/S	▲	▲	▲	▲		▲		▲		-
OKC 200 NTRR/BP	▲	▲	▲	▲		▲		▲		-
OKC 300 RR/BP/S	▲	▲	▲	▲		▲		▲		-
OKC 500 RR/BP/S	▲	▲	▲	▲		▲		▲		-
OKC 750 NTRR/BP	▲	▲	▲	▲		▲		▲		▲
OKC 1000 NTRR/BP	▲	▲	▲	▲		▲		▲		▲
OKC 200 NTR/HP	▲	▲	▲	-		-		-		-
OKC 250 NTR/HP	▲	▲	▲	-		-		-		-
OKC 300 R/HP/S	▲	▲	▲	▲		▲		-		-
OKC 500 R/HP/S	▲	▲	▲	▲		▲		▲		-
OKC 750 NTR/HP	▲	▲	▲	▲		▲		▲		▲
OKC 1000 NTR/HP	▲	▲	▲	▲		▲		▲		▲
OKC 200 NTR/HR 120	▲	▲	▲	▲		▲		▲		-
OKC 300 NTR/HR 100	▲	▲	▲	▲		▲		▲		-
OKC 200 NTRR/SOL	▲	▲	▲	▲		▲		▲		-
OKC 300 NTRR/SOL	▲	▲	▲	▲		▲		▲		-
OKC 400 NTRR/HP/SOL	▲	▲	▲	▲		▲		▲		-
OKC 500 RR/HP/SOL/S	▲	▲	▲	▲		▲		▲		-

* s prodlouženou chladnou částí, ▲ lze montovat, - nelze montovat

TABULKY PŘÍSLUŠENSTVÍ

MOŽNOSTI MONTÁŽE PŘÍRUBOVÝCH ELEKTRICKÝCH TOPNÝCH JEDNOTEK ŘADY TPJ

Typ	TPJ 150-8/2,5 kW	TPJ 150-8/3,0 kW	TPJ 150-8/4,0 kW	TPJ 150-8/6,0 kW	TPJ 150-8/7,5 kW	TPJ 150-8/9,0 kW	TPJ 150-8/12 kW	TPJ 150-8/15 kW	SE 377	SE 378
OKCE 300 S	●	●	●	●	●	●	●	-	-	-
OKCE 500 S	●	●	●	●	●	●	●	●	-	-
OKCE 750 S	■	■	■	■	■	■	■	■	▲	▲
OKCE 1000 S	■	■	■	■	■	■	■	■	▲	▲
OKC 160 NTR/BP	-	-	-	-	-	-	-	-	-	-
OKC 200 NTR/BP	-	-	-	-	-	-	-	-	-	-
OKC 300 R/BP/S	●	●	●	●	●	●	-	-	-	-
OKC 500 R/BP/S	●	●	●	●	●	●	-	-	-	-
OKC 750 NTR/BP	■	■	■	■	■	■	■	■	▲	-
OKC 1000 NTR/BP	■	■	■	■	■	■	■	■	▲	▲
OKF 200 NTR/S	●	●	●	●	●	●	●	-	-	-
OKC 300 R/F/S	●	●	●	●	●	●	●	-	-	-
OKC 200 NTRR/BP	-	-	-	-	-	-	-	-	-	-
OKC 300 RR/BP/S	●	●	●	●	●	●	-	-	-	-
OKC 500 RR/BP/S	●	●	●	●	●	●	-	-	-	-
OKC 750 NTRR/BP	■	■	■	■	■	■	■	■	▲	-
OKC 1000 NTRR/BP	■	■	■	■	■	■	■	■	▲	▲
OKC 200 NTR/HP	-	-	-	-	-	-	-	-	-	-
OKC 250 NTR/HP	-	-	-	-	-	-	-	-	-	-
OKC 300 R/HP/S	▲	▲	▲	▲	▲	▲	-	-	-	-
OKC 500 R/HP/S	▲	▲	▲	▲	▲	▲	-	-	-	-
OKC 750 NTR/HP	■	■	■	■	■	■	■	-	-	-
OKC 1000 NTR/HP	■	■	■	■	■	■	■	■	▲	▲
OKC 300 NTR/HR 100	▲	▲	▲	▲	▲	▲	-	-	-	-

▲ lze montovat, ■ lze montovat jen s redukční přírubou 225/150, ● lze montovat jen s redukční přírubou 210/150, - nelze montovat

TABULKY PŘÍSLUŠENSTVÍ

MOŽNOSTI MONTÁŽE TOPNÝCH PŘÍRUBOVÝCH JEDNOTEK ŘADY TPK

Typ	TPK 150-8/2,2 kW	TPK 150-8/3,3 kW	TPK 210-12/2,2 kW	TPK 210-12/3,3 kW	TPK 210-1-12/6 kW	TPK 210-1-12/9 kW	TPK 210-12/12 kW
OKCE 160 S	-	-	▲	▲	▲	-	-
OKCE 200 S	-	-	▲	▲	▲	-	-
OKCE 250 S	-	-	▲	▲	▲	-	-
OKCE 300 S	-	-	▲	▲	▲	▲	▲
OKCE 500 S	-	-	▲	▲	▲	▲	▲
OKCE 750 S	-	-	■	■	■	■	■
OKCE 1000 S	-	-	■	■	■	■	■
OKC 160 NTR/BP	▲	▲	-	-	-	-	-
OKC 200 NTR/BP	▲	▲	-	-	-	-	-
OKC 300 R/BP/S	-	-	▲	▲	▲	-	-
OKC 500 R/BP/S	-	-	▲	▲	▲	-	-
OKC 750 NTR/BP	-	-	■	■	■	■	■
OKC 1000 NTR/BP	-	-	■	■	■	■	■
OKF 200 NTR/S	-	-	▲	▲	▲	-	-
OKC 300 F/R/S	-	-	▲	▲	▲	▲	▲
OKC 200 NTRR/BP	▲	▲	-	-	-	-	-
OKC 300 RR/BP/S	-	-	▲	▲	▲	-	-
OKC 500 RR/BP/S	-	-	▲	▲	▲	-	-
OKC 750 NTRR/BP	-	-	■	■	■	■	■
OKC 1000 NTRR/BP	-	-	■	■	■	■	■
OKC 200 NTR/HP	▲	▲	-	-	-	-	-
OKC 250 NTR/HP	▲	▲	-	-	-	-	-
OKC 300 R/HP/S	▲	▲	-	-	-	-	-
OKC 500 R/HP/S	▲	▲	-	-	-	-	-
OKC 750 NTR/HP	-	-	■	■	■	■	■
OKC 1000 NTR/HP	-	-	■	■	■	■	■
OKC 300 NTR/HR 100	▲	▲	-	-	-	-	-
OKC 400 NTRR/HP/SOL	▲	▲	-	-	-	-	-
OKC 500 NTRR/HP/SOL	▲	▲	-	-	-	-	-

▲ lze montovat, ■ lze montovat jen s redukční přírubou 225/210, – nelze montovat